

Tent Set-up Instructions

NOTE: ALL SIDE POLES MUST BE OVER POLE TIPS.

1. Spread out tent and ropes. Drive stakes 3ft out from edge of tent. Two at each corner, one at each side pole position.
2. Fasten ropes to stakes leaving looped end and about 7ft of slack
3. Set up two piece side poles with tips through grommets. Angle poles at about 45 degrees.
4. Set up center pole. 15x15 center poles have 3 sections to them. 20x20 and 20x30 center poles have 4 sections(short pole is bottom)
5. Push side pole to vertical. Adjust and tighten side ropes.
6. Take small rope attached to the top center of canopie, pull straight down and wrap around center pole and tie to pole.

10 x 10	15 x 15	20 x 20	20 x 30
Red Pole Bag	Blue Pole Bag	Yellow Pole Bag	White Pole Bag
Red Stake Box	Brown Stake Box	Brown Stake Box	Gray Stake Box
4 - Side Poles	8- Side Poles	8 – Side Poles	10 – Side Pole
4 – top	8 – top	8 – top	10 – top
4 – bottoms	8 – bottoms	8 – bottoms	10 – bottoms
1–3 pc Center Pole	1–3 pc Center Pole	1–3 pc Center Pole	2–4 pc Center Pole
Top	Top	Top	2 Top
Middle	Middle	Middle	4 Middle
Short Bottom	Long Bottom	Short Bottom	2 Short Bottom
9- Ropes	13- Ropes	13- Ropes	15- Ropes
8- Stakes	12- Stakes	12- Stakes	14- Stakes

20 x 40
Black Stake Box
12- Wood Side poles
3- Wood Center Poles
16- Ropes

If you have a problem with the
product or a question please call us:
517-784-4961
Thanks Kutcha's Party Rental

**KUTCHA'S PARTY RENTAL IS ON YOUTUBE. WATCH SETUP LOCATED IN DEMO
VIDEOS (RED&WHITE TENT) FOR MORE HELPFUL TIPS!**